

VOICE e-DIY BOM

Qty	Value	Device	Part number	Note
5	CA3080	OTA	e-bay / UTsource / LittleDiode etc.	
1	4 PIN	MOLEX CONNECTOR	538-70551-0003	Only needed if you got the crimp tool and can build cables. Otherwise it's OK to hardwire.
21	25k	TRIM POTENTIOMETER PTC10V	531-PTC10V-25K	
22	50k	9mm POTENTIOMETER	688-RK09D1130A1L	
3	3.5mm jack	3.5mm JACK	502-35PM1	
24	BROWN	BANAN JACKS	530-108-0908-1	
32	GREY	BANAN JACKS	530-108-0913-1	
5	RED	BANAN JACKS	530-108-0902-1	
5	GREEN	BANAN JACKS	530-1080904-1	