

73◀▶75

THE SERGE PEOPLE'S SYNTHESIZER, REVISITED

KIT MANUAL

73 - 75

INTRODUCTION

BUILDING YOUR KIT

WELCOME TO THE KIT MANUAL FOR ASSEMBLING THE 73-75 DIY KIT. THIS MANUAL CONTAINS THE BASIC INFORMATION NEEDED TO ASSEMBLE THE KIT, BEFORE STARTING IT'S A GOOD IDEA TO GATHER AS MUCH INFORMATION ON THE BUILD AS POSSIBLE. SEARCH FORUM THREADS FOR THINGS THAT BUILDERS BEFORE YOU MIGHT HAVE ENCOUNTERED AND SOLVED. THERE'S NO REASON FOR YOU TO SOLVE WHAT SOMEONE ELSE ALREADY HAVE FIGURED OUT!

IT'S ALSO A GOOD IDEA TO READ THROUGH THE OLD SERGE INSTRUCTIONS, FOUND HERE - <http://www.serge.synth.net/documents/kit/kbm.html> BEFORE STARTING.

A FEW POINTERS BEFORE STARTING:

1, MODULES ARE NOT CONNECETD. SO THEY CAN BE TESTED INDIVIDUALLY, BUT IT ALSO MEANS YOU HAVE TO RUN POWER WIRES TO EACH AND EVERYONE

2, POWER IS APPLIED TO PADS W, X, Y, Z. AND WIRES HAVE THE FOLLOWING

7 3 - 7 5

STANDARD:

W, GND (BLACK)

X, +12V (RED)

Y, +6V (GREEN)

Z, -12V (WHITE)

3, RESISTORS WITHOUT SUFFIX IS OHMS, SO 15 IS 15 OHMS. IF IT'S A PREFIX IT'S 0.x, SO u1 IS 100n.

4, MAKE SURE EVERYTHING WORKS BEFORE PUTING ON THE PANEL! NO REALLY, MAKE SURE IT'S 100% OPERATIONAL BEFORE FINAL ASSEMBLY. EVERYTHING CAN BE TESTED WITHOUT MOUNTING THE JACKS. USE CROCODILE CLIPS AND RESISTOR LEGS AS PATCH CORDS IF NEEDED.

5, BE CREATIVE! THE COLORS FOR KNOBS AND JACKS ARE JUST SUGGESTIONS. IF YOU FEEL LIKE DOING A YELLOW/PURPLE/ORANGE COMBINATION INSTEAD, PLEASE DO. DON'T LIKE THE KNOBS? CHANGE THEM! NOTHING IS SET IN STONE, IT'S UP TO YOU TO SHAPE THIS TO THE INSTRUMENT YOU WANT TO PLAY. A GOOD LOOKING INSTRUMENT PLAYS BETTER THAN AN UGLY ONE.

6, TAKE YOUR TIME, HAVE FUN! NO REASON TO STRESS AND MAKE ERRORS JUST BECAUSE YOU WANT TO PLAY. THE JOURNEY IS MORE IMPORTANT THAN THE DESTINATION.

73 - 75

OSCILLATOR

BOM		1	4k7
-----		6	22k
Qty	Value	2	33k
1	33p	1	82k
1	47p	2	100k
2	82p	5	330k
1	10n	2	1M
1	27n	2	1M5
1	4u7	1	3M3
2	47u	1	4M7
		3	25k TRIMMER
3	1N4148	4	25k LINEAR POTENTIOMETER
3	2N3904		
1	LM3900		
1	15		
4	330		
1	10k		
1	15k		
3	1k		
1	2k2		
2	3k3		

7 3 - 7 5


TRIM INSTRUCTIONS

THERE'S THREE TRIMMERS FOR THE OSCILLATOR.

TRIMMER 1, INITIAL OFFSET. SET FOR DESIRED LOWEST FREQUENCY. SUGGESTED 5-10Hz.

TRIMMER 2, RANGE. ADJUST FOR SPAN OF 5-10Hz TO 10-14kHz.


TRIMMER 3, SINE ADJUSTMENT IN SAW TO SINE WAVESHAPER. ADJUST FOR CLEANEST POSSIBLE SINEWAVE OUTPUT.



BACKSIDE OF CIRCUIT BOARD

73-75

OSCILLATOR SCHEMATIC



73 - 75

TRIPLE WAVE SHAPER

BOM

Qty Value

3 100p

3 470n

3 47u

12 1N4148

1 LM3900N

3 220

6 22k

3 220k

3 150k

9 1M5


3 25k TRIMMER

3 25k POTENTIOMETER

7 3 - 7 5

TRIM INSTRUCTIONS


THERE'S ONE TRIMMER FOR EACH SECTION OF THE TRIPLE WAVE SHAPER. ADJUST THE TRIMMER (WITH THE INPUT PUT TURNED FULLY CLOCKWISE) SO THE OUTPUT AMPLITUDE IS THE SAME AS THE INPUT AMPLITUDE.



BACKSIDE OF CIRCUIT BOARD

73 - 75

TRIPLE WAVE SHAPER SCHEMATIC



73 - 75


PEAK AND TROUGH

BOM

Qty	Value
10	1N4148
2	2N3904
2	2N3906
5	2k2
1	15k
1	150k
1	220k

73 - 75

PEAK AND TROUGH SCHEMATIC



73 - 75

TRIPLE COMPARATOR

BOM

Qty Value

3 100p

3 470n

3 47u

12 1N4148

1 LM3900N

3 220

6 22k

3 220k

3 150k

9 1M5


3 25k TRIMMER

3 25k LINEAR POTENTIOMETER

73 - 75

TRIM INSTRUCTIONS


ONE TRIMMER FOR ALL THREE COM-
PARATORS. INPUT A SAWTOOTH 0-5V,
ADJUST FOR 50% PULSWIDTH WITH POT
AT NOON.



BACKSIDE OF CIRCUIT BOARD

73 - 75

TRIPLE COMPARATOR SCHEMATICS



73 - 75

DUAL PROCESSOR

BOM

Qty	Value
-----	-------

4	10n
---	-----

4	1N4148
---	--------

4	LM741
---	-------

2	220
---	-----

2	820
---	-----

2	10k
---	-----


12	100k
----	------

2	220k
---	------

8	25k LINEAR POTENTIOMETER
---	--------------------------

73 - 75

DUAL PROCESSOR SCHEMATICS



73 - 75

GATE


BOM		3	25k	TRIMMER
-----		1	25k	LINEAR POTENTIOMETER
Qty	Value			
1	220p			
1	10n			
1	470n			
1	1N4148			
1	LM307			
1	CA3080			
3	2N3906			
3	330			
2	1k			
1	2k2			
2	15k			
4	22k			
2	33k			
2	68k			
4	220k			

7 3 - 7 5

TRIM INSTRUCTIONS

INPUT A AUDIO SOURCE INTO
AC-INPUT. SET 3 TO CENTER.
MONITOR OUTPUT AND ADJUST 1
AND 2 FOR SAME OUTPUT AMPLI-
TUDE AS INPUT.


INPUT DC SOURCE INTO DC IN.
ADJUST 3 FOR MINUM OUTPUT
OFFSET.



BACKSIDE OF CIRCUIT BOARD

73 - 75

GATE SCHEMATICS



73 - 75

RING MODULATOR

BOM		3	25k	TRIMMER
-----		1	25k	LINEAR POTENTIOMETER
Qty	Value			
1	10n			
1	220p			
2	470n			
1	1N4148			
1	LM307			
1	CA3080			
3	2N3906			
3	330			
2	1k			
1	2k2			
2	15k			
2	22k			
4	47k			
1	150k			
4	220k			
2	68k			

7 3 - 7 5


TRIM INSTRUCTIONS

START BY SETTING 3 TO CENTER POSITION, SET 2 TO FULL CCW. INPUT A 500Hz SAWTOOTH, INTO X AND PAD A. ADJUST 1 FOR A SYMMETRICAL OUTPUT.



DISCONNECT SAWTOOTH FROM X. ADJUST 3 FOR MINUM FEED THROUGH. REPEAT ADJUSTING 1 NOW THAT 3 IS SET.


CONNECT 1kHz SAWTOOTH TO BOTH X AND Y. ADJUST 2 FOR A SYMMETRICAL OUTPUT.



BACKSIDE OF CIRCUIT BOARD

73 - 75

RING MODULATOR SCHEMATICS




73 - 75

PREAMP & REVERB

BOM		1	220k
-----		2	33k
Qty	Value	1	470k
1	100p	1	6k8
3	10n		
1	10p	2	25k LINEAR POTENTIOMETER
1	220n		
1	2n2	2	RCA CONNECTOR
3	47p		
6	22u		
1	2N3904		
1	LM1458		
1	LM3900		
2	2N3906		
1	220		
4	330		
14	100k		
2	10k		
1	150k		
2	1M		

73 - 75

REVERB SCHEMATICS



73 - 75

POSITIVE SLEW

BOM

Qty	Value
-----	-------

3	100p
---	------

3	470n
---	------

3	47u
---	-----

12	1N4148
----	--------

1	LM3900N
---	---------

3	220
---	-----

6	22k
---	-----

3	220k
---	------

3	150k
---	------

9	1M5
---	-----

3	25k	TRIMMER
---	-----	---------


3	25k	POTENTIOMETER
---	-----	---------------

73 - 75

TRIM INSTRUCTIONS

PATCH BOTTOM PULSE OUTPUT TO
INPUT FOR CYCLE ACTION.
ADJUST TRIMMER TO TASTE.


ORIGINAL TRIMMING IS MAX FRE-
QUENCY OF 1KHz FOR TOP SLEW
AND 500Hz FOR BOTTOM SLOW. IT
MIGHT BE PREFERABLE TO SET
THEM TO THE SAME FREQUENCY
THOUGH...



BACKSIDE OF CIRCUIT BOARD

73 - 75

POSITIVE SLEW SCHEMATICS



73 - 75

NEGATIVE SLEW


BOM		2	1M	
-----		2	25k	TRIMMER
Qty	Value	4	25k	LINEAR POTENTIOMETER
2	10n			
2	120p			
2	330n			
2	CA3086			
2	LM3900			
2	33			
4	220			
4	4k7			
4	6k8			
6	10k			
4	18k			
4	22k			
2	100k			
6	220k			
2	330k			
8	470k			
2	820k			

73 - 75

TRIM INSTRUCTIONS

PATCH PULSE OUTPUT TO INPUT
FOR CYCLE ACTION. ADJUST
TRIMMER TO TASTE.


ORIGINAL TRIMMING IS MAX FRE-
QUENCY OF 1KHz FOR TOP SLEW
AND 500Hz FOR BOTTOM SLOW. IT
MIGHT BE PREFERABLE TO SET
THEM TO THE SAME FREQUENCY
THOUGH...



BACKSIDE OF CIRCUIT BOARD

73 - 75

NEGATIVE SLEW SCHEMATICS



73 - 75

ENVELOPE

BOM		2	68k	
-----		2	82k	
Qty	Value	2	22k	
1	100p	1	2k2	
1	10n	5	100k	
1	220p	2	330k	
1	33p	7	470k	
1	470n	2	1M	
		2	1M5	
6	1N4148			
6	2N3904	1	10k	TRIMMER
2	LM3900	1	25k	TRIMMER
3	2N3906	4	25k	LINEAR POTENTIOMER
1	33			
5	470			
2	10M			
2	1k			
1	3k3			
2	6k8			
1	15k			
7	33k			

7 3 - 7 5

TRIM INSTRUCTIONS

PATCH END TO START, SET RISE
AND FALL CCW. ADJUST 1 UNTIL
YOU HAVE 4.00V AT PIN 10 OF
THE BOTTOM LM3900.


PLUG A GATE OUTPUT INTO THE
HOLD WHILE THE ENVELOPE
CYCLES. ADJUST 2 SO THE OUTPUT
IS STABLE



BACKSIDE OF CIRCUIT BOARD

73 - 75

ENVELOPE SCHEMATICS



73 - 75

POWER SUPPLY

BOM

FOR A SLIM VERSION OF THE PSU.

Qty Value

OMIT EVERYTHING BUT THE POLAR-

3 100n

IZED CAPS IN THE +12V AND -12V

3 1u

SECTION. BRIDGE MARKED PINS ON

4 10u

THE REGULATORS. AND REPLACE THE

6 1N4004

±15V DC-DC CONVERTER WITH A ±12V

2 LM317

INSTEAD. THE +6V LINE CAN BE RUN

1 LM337

WITH A MUCH SMALLER HEATSINK

1 100nH

THAN SUGGESTED, SINCE CURRENT

3 LED BUILDERS CHOICE.

CONSUMPTION ON SAID LINE IS VERY

1 S24DE150R5PDFA

LOW.

3 220

ADJUST ALL TRIMMERS FOR +12.00V

1 470

AT PAD X, +6.00V AT PAD Y, AND

2 10k

-12.00V AT PAD Z.

2 1k5

1 4k7

3 500 MULTI TURN TRIMMER

3 TO-220 HEATSINK

73 - 75

PSU SCHEMATICS

